#### CALIFORNIA ENERGY COMMISSION

1516 NINTH STREET SACRAMENTO, CA 95814-5512 www.energy.ca.gov



# Guidelines for Residential HERS Compliance Documentation Registered on or After October 1, 2010 – Newly Constructed Buildings and Additions

Starting January 1, 2010, the 2008 Building Energy Efficiency Standards required all compliance documentation for newly constructed low-rise residential buildings requiring HERS verification and demonstrating compliance under the multiple orientation alternative to be registered with the appropriate HERS Provider. On October 1, 2010, this requirement was extended to all low-rise residential buildings requiring HERS field verification.

To ensure compliance with this regulation, please follow these guidelines for newly constructed dwellings and additions:

- Look for and review a registered Certificate(s) of Compliance (CF-1R) submitted with the building plans.
   A registered CF-1R will have a HERS Provider's watermark and a unique 12-digit registration number
   followed by 13 zeros located at the bottom of each page (see registration number guide and example
   registered CF-6R on the following pages).
- Look for and review an electronically signed and registered Installation Certificate(s) (CF-6R) posted by the installing contractor at the building site. The first 12 digits of its 21-digit registration number (followed by four zeros) will match the associated CF-1R's registration number.
- At final inspection, look for and review an electronically signed and registered Certificate(s) of Field Verification and Diagnostic Testing (CF-4R) posted at the building site by a certified HERS rater. The first 20 digits of its 25-digit registration number will match the associated CF-1R's registration number.
- At final inspection, verify that the work listed on the CF-1R has actually been completed and that the installed equipment matches what is listed on the CF-6R posted at the building site.
- You may verify that any registered compliance document is valid by searching for it on the appropriate
  HERS Provider's website using the document's registration number. (Currently CalCERTS
  [www.calcerts.com] is the only HERS Provider certified for newly constructed residential buildings and
  additions.) If the submitted CF-1R, 6R, or 4R does not exactly match the version posted on the
  provider's website, or if there is no electronic version available, its validity should be questioned.

To combat fraud, the California Energy Commission recommends that building department personnel use the HERS Providers' websites to perform random verification checks of registered compliance documents. (See HERS Providers' website information on next page.)

### **Registration Number Guide**

The vear (eg 3rd digit of year 2010)  O year (eg 3rd digit of year 2010)  CF-1R Type (N=new residential, A= 0 numeric (sequential othrough 9)  O CF-6R Type (E=envelope, L=lightir on numeric digit eg  CF-6R Type (E=envelope, L=lightir on numeric digit eg  O numeric (sequential othrough 9)  No numeric (sequential othrough 9)	year (eg 3rd digit of year 2010)  year (eg 4th digit of year 2010)  CF-1R Type (N=new residential, A=alteration residential, D=addition residential)  numeric (sequential 0 through 9)  CF-6R Type (E=envelope, L=lighting, M=mechanical)  CF-6R Type (E=envelope, L=lighting, M=mechanical)  CF-6R Type (E=envelope, L=lighting, M=mechanical)  CF-6R Type (second numeric digit eg "2" from the mech-21)  numeric (sequential 0 through 9)
O - N O O O 7 3 2 1 B - M 2 1 O O O 5 2 A 99,999,999 numbers + O	(sequential 0 through 9) (pe (E=ervelope, L=lighting, M=mechanical) (ppe (first numeric digit eg."2" from the mech-21) (sequential 0 through 9)
- N 0 0 0 7 3 2 1 B - M 2 1 0 0 0 5 2 A 9,999,999 numbers + 0	(sequential 0 through 9)
N 0 0 0 7 3 2 1 B - M 2 1 0 0 0 5 2 A 9,999,999 numbers + 0	(Sequential 0 through 9) (pe (E=envelope, L=lighting, M=mechanical) (ppe (first numeric digit eg "2" from the mech-21) (sequential 0 through 9)
0 0 0 7 3 2 1 B - M 2 1 0 0 0 5 2 A 9,999,999 numbers + 0	(sequential 0 through 9) (pe (E=ervelope, L=lighting, M=mechanical) (ppe (first numeric digit eg."2" from the mech-21) (ppe (second numeric digit eg."1" from the mech-21) (sequential 0 through 9)
0 0 7 3 2 1 B - M 2 1 0 0 0 5 2 A 9,999,999 numbers + 0	(sequential 0 through 9) (Level (alpha only: A=first Issuance; then sequential B through 2) (Pee (E=envelope, L=lighting, M=mechanical) (Pee (first numeric digit eg."2" from the mech-21) (Sequential 0 through 9) (Sequential 0 through 9)
0 7 3 2 1 B - M 2 1 0 0 0 5 2 A  99,999 numbers + 0  CF-1R  CF-6R  use 000000000 for  CF-1R	(sequential 0 through 9) (pe (first numeric digit eg "2" from the mech-21) (ppe (second numeric digit eg "1" from the mech-21) (sequential 0 through 9)
7 3 2 1 B - M 2 1 0 0 0 5 2 A 9 numbers + 0  CF-1R  - M 2 1 0 0 0 5 2 A  99,999 numbers  CF-6R  use 000000000 for  CF-1R	(sequential 0 through 9) (pe (E=ervelope, L=lighting, M=mechanical) (ppe (first numeric digit eg "2" from the mech-21) (ppe (second numeric digit eg "1" from the mech-21) (sequential 0 through 9)
3 2 1 B - M 2 1 0 0 0 5 2 A 99,999 numbers CF-6R use 000000000 for CF-1R	(sequential 0 through 9) (sequential 0 through 9) (sequential 0 through 9) (sequential 0 through 9) (Level (alpha only: A=first Issuance; then sequential B through 2) (pe (E=envelope, L=lighting, M=mechanical) (ppe (first numeric digit eg "2" from the mech-21) (ppe (second numeric digit eg "1" from the mech-21) (sequential 0 through 9)
2 1 B - M 2 1 0 0 0 5 2 A +0 99,999 numbers	(sequential 0 through 9) (sequential 0 through 9) Level (alpha only: A=first Issuance; then sequential B through 2)  //Pe (E=envelope, L=lighting, M=mechanical)  //Pe (first numeric digit eg "2" from the mech-21)  //Pe (second numeric digit eg "1" from the mech-21)  (sequential 0 through 9)
1 B - M 2 1 0 0 0 5 2 A 99,999 numbers  CF-6R use 000000000 for CF-1R	(sequential 0 through 9)  Level (alpha only: A=first Issuance; then sequential B through 2)  //pe (E=envelope, L=lighting, M=mechanical)  //pe (first numeric digit eg "2" from the mech-21)  //pe (second numeric digit eg "1" from the mech-21)  (sequential 0 through 9)
B - M 2 1 0 0 0 5 2 A 99,999 numbers  CF-6R use 000000000 for CF-1R	Level (alpha only: A=first Issuance; then sequential B through 2)  //pe (E=ervelope, L=lighting, M=mechanical)  //pe (first numeric digit eg "2" from the mech-21)  //pe (second numeric digit eg "1" from the mech-21)  (sequential 0 through 9)
- M 2 1 0 0 0 5 2 A 99,999 numbers  CF-6R use 000000000 for CF-1R	lope, L-lightin meric digit eg numeric digit 0 through 9)
M 2 1 0 0 0 5 2 A 99,999 numbers  CF-6R use 000000000 for CF-1R	lope, L=lightin neric digit eg' numeric digit 0 through 9)
2 1 0 0 0 5 2 A 99,999 numbers CF-6R use 000000000 for CF-1R	nericdigit eg numericdigit 0 through 9)
1 0 0 0 5 2 A 99,999 numbers CF-6R use 000000000 for CF-1R	numeric digit 0 through 9)
0 0 0 5 2 A 99,999 numbers CF-6R use 000000000 for CF-1R	
0 0 5 2 A 99,999 numbers CF-6R 00000000 for CF-1R	
0 5 2 A 9 numbers	(sequential 0 through 9)
5 2 A	(sequential 0 through 9)
2 A	(sequential 0 through 9)
200	(sequential 0 through 9)
	Revision Level (alpha only: A=first Issuance; then sequential B through Z)
951	
M CF	CF-4R Type (E=envelope, L=lighting, M=mechanical)
∾ CF-4R Type (first numeric digit	pe (first numeric digit eg "2" from the mech-21)
1 -4R 000 fo	CF-4R Type (second numeric digit eg "1" from the mech-21)
C r -6R	Revision Level (alpha only: A=first Issuance; then sequential B through Z)

Note: Only capitalized alpha digits are used, to avoid confusion with the number Zero "0", the letter "O" is not used, and to avoid confusion with the number One "1", the letter "I" is not used.

#### **HERS Providers**

Approved for Newly Constructed Buildings, Additions, Alterations, and New Solar Homes Partnership Programs

CalCERTS - www.calcerts.com

Approved for Alterations Only

CBPCA - www.cbpca.org

## **Example Registered CF-6R from CalCERTS**

		CF-6R-ME	CH-20-HERS	
DuctLeakage Test- Completely New or Replacem	ent Duct System	(	Page 1 of2)	
Site Address: 20400 Via Sansovino, Northridge CA 91324 (System 1)	Enforcement Agency: County of Los Angeles	Permit Num 09010-2000		
Enter the Duct System Name or Identification/Tag: <b>Sys</b>	tem 1			
Enter the Duct System Location or Area Served: LIVIN	~			
Note: Submit one Installation Certificate for each duct s dwelling.	ystem that must demonst	rate co <i>mplian</i>	ce in the	
This ærtificate is required for complianæ for completely construction, and also for completely new or replaceme. dwellings, a completely new or replacement duct system system (e.g., register boots, air handler, coil, plenums, sealed.	nt duct systems in existing n can also indude existing	i dwellings. Fo parts of the o	or existing original duct	HERS
Duct Leakage Diagnostic Test - completely new or replac Enter a value for the Allowed Leakage (CFM) for the duct syste		alue entered m	ust be the	Provide
VLLDCS criteria ar ane af the three calculated leakage rates de	scribed below.	- 00 - 00	and the the	waterm
Verified Law Leakage Ducts in Conditioned Space (VLLD credit for verified law leakage ducts in conditioned space is sho CF-18, the leakage to autistic test method must be used to ver and 25 CFM must be entered for Allowed Leakage.	iwn in the special features sec	ction of the	Allowed Leakage (CFM)	
is reported on the CF-1R as 1%, then use aleakage factor of D.	DJ the Calculations below.	The same of the sa		
☑ Cooling system method:  Nominal capacity of condenser in Tons <u>4</u> x 4BB x <i>leakage facto</i> ☐ Heating system method:  21.7 x Output Capacity in Thousands of Btu/hr x <i>lea</i>	wage factor = CFM	S	inc	0
☑ Cooling system method:  Nominal capacity of condenser in Tons <u>4</u> x 4BB x <i>leakage facto</i> ☐ Heating system method:  21.7 x Output Capacity in Thousands of Btu/hr x <i>lea</i>			inc	. 0
☑ Cooling system method:  Nominal capacity of condenser in Tons <u>4</u> x 4BB x <i>leakage facto</i> ☐ Heating system method:  21.7 x Output Capacity in Thousands of Btu/hr x <i>lea</i>		ble duct	Actual Leakage (CFM)	
✓ Cooling system method:  Nominal capacity of condenser in Tons <u>d</u> x 4BB x reakage facto  ☐ Heating system method:  21.7 x Output Capacity in Thousands of Btu/hr x rea  ☐ Measured air flow method (RAJ.J):  Enter measured fan flow in CFM here x reakage fact  Enter value far Actual leakage (CFM) in the right column, from leakage pressurization test procedure from Reference Resident  List Actual	Kage factor =CFM or =CFM n measurement using applicatival Appendix RAJ.1(CFM @ 25tual Leakage from duct leakage	ble duct 5 Pa).	Leakage	
✓ Cooling system method:  Nominal capacity of condenser in Tons <u>d</u> x 4BB x reakage facto  Heating system method:  21.7 xOutput Capacity in Thousands of Btu/hr x rea  Measured air flow method (RAJ.J):  Enter measured fan flow in CFM here x reakage facto  Enter value for Actual leakage (CFM) in the right column, from leakage pressurization test procedure from Reference Resident  List Actual Leakage is equal to or less than Allowed L	Kage factor =CFM  or =CFM  n measurement using application in the properties of the propert	ble duct 5 Pa). ge test(CFM)	Leakage (CFM)	. @
✓ Cooling system method:  Nominal capacity of condenser in Tons 4 × 400 × reakage factors and the system method:  21.7 × Output Capacity in Thousands of Btu/ni × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are greatered fan flow in CFM here × reakage factors are greatered from Reference Resident List Actual Leakage is equal to or less than Allowed Leakage if Actual Leakage is equal to or less than Allowed Leakage is	ikage factor =CFM  or =CFM  n measurement using application for the properties of the properties of the decidence of the properties of the decidence of the decidence of the duct systems of the	Die duct S Pa). ge test(CFM) De met, a -existing tem. A HERS	Leakage (CFM) 85	
✓ Cooling system method:  Nominal capacity of condenser in Tons 4 × 400 × reakage factors and the system method:  21.7 × Output Capacity in Thousands of Btu/ni × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are measured fan flow in CFM here × reakage factors are greatered fan flow in CFM here × reakage factors are greatered from Reference Resident List Actual Leakage is equal to or less than Allowed Leakage if Actual Leakage is equal to or less than Allowed Leakage is	ikage factor =CFM  or =CFM  n measurement using application for the properties of the properties of the duct leakage from duct leakage at leakage rate criteria cannot age is coming only from a preside portions of the duct systitist Actual Leakage from smoothing the properties of the duct systitist Actual Leakage from smoothing the duct systems of t	ole duct S Pa). ge test(CFM) De met, a -existing tem. A HERS oke test(CFM)	Leakage (CFM) 85	
✓ Cooling system method:  Nominal capacity of condenser in Tons 4 × 400 × reakage factors and the system method:  21.7 × Output Capacity in Thousands of Btu/ni × reakage factors are capacity in Thousands of Btu/ni × reakage factors are capacity in Thousands of Btu/ni × reakage factors are capacity in the right column, from leakage pressurization test procedure from Reference Resident List Actual Leakage is equal to or less than Allowed Life complete replacement of duct systems only. If the 6 percers smaller test should be performed to verify that the excess leakage must verify the installation (No sampling allowed).	ikage factor =CFM  or =CFM  n measurement using application for the properties of the properties of the duct leakage from duct leakage at leakage rate criteria cannot age is coming only from a preside portions of the duct systitist Actual Leakage from smoothing the properties of the duct systitist Actual Leakage from smoothing the duct systems of t	ole duct S Pa). ge test(CFM)  . De met, a -existing tem. A HERS ake test(CFM)	Leakage (CFM) 85 ☑ Pass □ Fail	

For more information, visit <a href="www.energy.ca.gov/title24">www.energy.ca.gov/title24</a> and www.energyvideos.com, or call the Energy Standards Hotline at (800) 772-3300.